




The Shaffer Memorial Organ

Westwood United Methodist Church Los Angeles, California

The Shaffer Memorial Organ

Westwood United Methodist Church, Los Angeles, California

Schantz Organ Company, 1995

4 Manuals, 100 Ranks

CHANCEL ORGAN

GREAT ORGAN

32'	Dulciana I-II	(Choir)
16'	Geigen Diapason	73 pipes
8'	Open Diapason	61 pipes
8'	Geigen Diapason	(ext.)
8'	Rohrflöte	61 pipes
8'	Hohlflöte	*61 pipes
8'	Celeste	*54 pipes
4'	Principal	61 pipes
4'	Octave	61 pipes
4'	Spitzflöte	61 pipes
3 1/5'	Tenth	61 pipes
2 2/3'	Twelfth	61 pipes
2'	Fifteenth	61 pipes
2'	Waldflöte	61 pipes
1 3/5'	Seventeenth	61 pipes
II	Grave Mixture	122 pipes
IV	Mixture	244 pipes
III	Klein Mixture	183 pipes
III	Scharf	183 pipes
16'	Double Trumpet	61 pipes
8'	Trumpet	61 pipes
4'	Zink	(Choir)
	Tremulant	
	Cast Bells	(elec.)
	Glocken Harp	(elec.)
	Zimbelstern	10 bells
	Great to Great 16', 4'	
	Great Unison Off	
	Great off Manual II	
	Great on Manual IV	

SWELL ORGAN

16'	Lieblich Gedeckt	*85 pipes
8'	Diapason	61 pipes
8'	Bourdon	61 pipes
8'	Spire Flute	*61 pipes
8'	Gambe	61 pipes
8'	Gambe Celeste	*61 pipes
8'	Voix Celeste II	110 pipes
4'	Principal	61 pipes
4'	Traverse Flute	*68 pipes
4'	Lieblichflöte	(ext.)
2 2/3'	Nasard	61 pipes
2'	Flute	61 pipes
1 3/5'	Tierce	68 pipes
1'	Piccolo	61 pipes
IV	Plein Jeu	244 pipes
III	Cymbale	183 pipes

16'	Basson	*73 pipes
8'	Trompette	61 pipes
8'	Hautbois	(ext.)
8'	Oboe	61 pipes
5 1/3'	Cromorne Quint	61 pipes
4'	Clairon	61 pipes
8'	Vox Humana	61 pipes
	Tremulant	
	Cast Bells	(elec.)
	Timbrel Bells	(elec.)
	Swell to Swell 16', 4'	
	Swell Unison Off	

CHOIR ORGAN

16'	Dulciana	*73 pipes
8'	Diapason	61 pipes
8'	Stopped Diapason	61 pipes
8'	Erzähler	*73 pipes
8'	Erzähler Celeste	*61 pipes
8'	Dulcet II	(ext.)/54 pipes
4'	Principal	61 pipes
4'	Gemshorn	61 pipes
4'	Koppelflöte	*61 pipes
2 2/3'	Nasat	*61 pipes
2'	Octave	61 pipes
2'	Harmonic Piccolo	61 pipes
1 3/5'	Terz	61 pipes
1 1/3'	Larigot	61 pipes
8/9'	None	61 pipes
IV	Mixture	244 pipes
III	Zimbel	183 pipes
16'	Holzduzian	61 pipes
8'	English Horn	73 pipes
8'	Cromorne	61 pipes
4'	Rohrschalmei	61 pipes
	Tremulant	
8'	Tuba Major	(Solo)
8'	Trompette-en-chamade	(gallery)
	Harp	(elec.)
	Celesta	(elec.)
	MIDI	
	Choir to Choir 16', 4'	
	Choir Unison Off	
	Great on Manual I	
	Gallery Great on Manual I	
	Great/Choir Manual Transfer	

SOLO ORGAN

8'	Harmonic Flute	61 pipes
8'	Viola Pomposa	61 pipes
8'	Viola Celeste	61 pipes
8'	French Horn	73 pipes
8'	Clarinet	61 pipes
4'	Alphorn	(ext.)
	Tremulant	
8'	Tuba Major	73 pipes
16'	Trompeteria II	(gallery)
8'	Trompette-en-chamade	(gallery)
	Chimes	(elec.)
	MIDI	
	Solo to Solo 16', 4'	
	Solo Unison Off	

PEDAL ORGAN

32'	Contra Violone	(elec.)
32'	Contre Bourdon	(elec.)
16'	Open Diapason	32 pipes
16'	Geigen Diapason	(Great)
16'	Bourdon	*44 pipes
16'	Spire Flute (Sw)	*12 pipes
16'	Lieblich Gedeckt	(Swell)
16'	Dulciana	(Choir)
8'	Principal	32 pipes

8'	Geigen Diapason	(Great)
8'	Bourdon	(ext.)
8'	Spire Flute	(Swell)
8'	Lieblich Gedeckt	(Swell)
8'	Dulciana	(Choir)
5 1/3'	Quint	*32 pipes
4'	Fifteenth	32 pipes
4'	Rohrpfefe	32 pipes
2'	Flute	*32 pipes
II	Rauschquint	64 pipes
III	Mixture	*96 pipes
II	Cornet	(Swell)
32'	Bombarde	(elec.)
32'	Contra Fagott	(elec.)
16'	Trombone	*56 pipes
16'	Basson	(Swell)
16'	Fagott	(elec.)
8'	Trumpet	(ext.)
8'	Hautbois	(Swell)
8'	Holzduzian	(Choir)
4'	Clarion	(ext.)
4'	Hautbois	(Swell)
	Cast Bells	(elec.)
	Harp	(elec.)

**from former Möller organ*

GALLERY ORGAN

(Console preparations only, except for Trompette-en-chamade, Celesta, Glockenspiel and Zimbelstern)

Gallery Great

16'	Montre	
8'	Montre	
8'	Flûte à cheminée	
8'	[Sw] Quintaton	
4'	Prestant	
4'	Flûte harmonique	
2 2/3'	Nasard	
2'	Flûte à bec	
1 3/5'	Tierce	
IV	Fourniture	
IV-VI	Plein Jeu (draws IV)	
16'	[Sw] Douçaine-Cromorne	
8'	Trompette	
	Tremulant	
16'	Trompeteria II	
8'	Trompette-en-chamade	73 pipes
	Celesta (chancel)	(elec.)
	Zimbelstern	5 bells
	Gallery Great to	
	Gallery Great 16', 4'	
	Gallery Great Unison Off	
	Gallery Great off Manual II	
	Gallery Great on Manual IV	

Gallery Swell

16'	Quintaton	
8'	Principal étroit	
8'	Voce Umana [G]	
8'	Bourdon	
8'	Flûte céleste II	
4'	Principal	
4'	Flûte conique	
2'	Doublette	
1 1/3'	Larigot	
IV	Cymbale	
16'	Douçaine-Cromorne	
8'	Hautbois	
8'	Voix humaine	
	Tremulant	
8'	[Gt] Trompette	
	Glockenspiel (chancel)	(elec.)
	Rosignol	
	Gallery Swell to Gallery	
	Swell 16', 4'	
	Gallery Swell Unison Off	
	Gallery Swell off Manual III	
	Gallery Swell on Manual IV	
	Gallery Monitor	
	Narthex Monitor	

Gallery Pedal

32''	Bourdon doux [Digital]	
16'	[Gt] Montre	
16'	Soubasse	
16'	[Sw] Quintaton	
8'	Octavebasse	
8'	Flûte bouchée	
4'	Octave	
4'	Flûte ouverte	
III	Fourniture	
16'	Bombarde	
16'	[Sw] Douçaine-Cromorne	
8'	[Gt] Trompette	
4'	[Sw] Cromorne	
8'	Trompette-en-chamade	
	Pedal Silent	
	Celestes/Tremulants Silent	

COUPLERS

Great to Pedal 8', 4'
 Gallery Great to Pedal 8'
 Swell to Pedal 8', 4'
 Gallery Swell to Pedal 8', 4'
 Choir to Pedal 8', 4'
 Solo to Pedal 8', 4'
 Swell to Great 16', 8', 4'
 Gallery Swell to Great 16', 8', 4'

Choir to Great 16', 8', 4'
 Solo to Great 16', 8', 4'
 Choir to Swell 8'
 Swell to Choir 16', 8', 4'
 Gallery Swell to Choir 8', 4'
 Solo to Choir 16', 8', 4'
 Swell to Solo 8'
 Choir to Solo 8'

MISCELLANEOUS ACCESSORIES

Solid-state combination system with 99 levels of memory

Up/Down memory level pistons (thumb)
 20 General pistons (thumb and toe)
 8 Great/Gallery Great thumb pistons
 8 Swell/Gallery Swell thumb pistons
 8 Choir thumb pistons
 8 Solo thumb pistons
 8 Pedal/Gallery Pedal pistons (thumb and toe)
 Setter thumb piston
 Setter lock switch
 Great divisional cancel nameplate
 Gallery Great divisional cancel nameplate
 Swell divisional cancel nameplate
 Gallery Swell divisional cancel nameplate
 Choir divisional cancel nameplate
 Solo divisional cancel nameplate
 Pedal divisional cancel nameplate
 Gallery Pedal divisional cancel nameplate
 General Cancel (Chancel and Gallery Organ)
 Gallery console cancel
 MIDI cancel
 Great to Pedal reversible (thumb and toe)
 Gallery Great to Pedal reversible (thumb and toe)
 Swell to Pedal reversible (thumb and toe)
 Gallery Swell to Pedal reversible (thumb and toe)
 Choir to Pedal reversible (thumb and toe)
 Solo to Pedal reversible (thumb and toe)
 Gallery reversibles to Chancel reversible (thumb)
 Tutti I reversible (thumb and toe)
 Tutti II reversible (thumb and toe)
 Tutti III reversible (thumb and toe)
 Tutti IV reversible (thumb and toe)
 32' Contra Violone reversible (toe)
 32' Contre Bourdon reversible (toe)
 32' Bombarde reversible (toe)
 32' Bourdon doux reversible (toe)
 Zimbelstern reversible (thumb and toe)
 Rossignol reversible (toe)
 All Swells to Swell reversible (thumb)
 Gallery Swell expression on Solo reversible (thumb)
 Gallery Console reversible (thumb)
 Reeds silent reversible (thumb)

Mixtures silent reversible (thumb)
 Manual 16's/Pedal 32's silent reversible (thumb)
 Chancel organ silent reversible (thumb)
 Gallery organ silent reversible (thumb)
 Signal light reversible (thumb)
 Indicator lights for:

Power
 Monitor Speakers
 All Swells to Swell
 Gallery Swell expression on Solo
 Gallery Console
 Reeds silent
 Mixtures silent
 Manual 16's/Pedal 32's silent
 Chancel organ silent
 Gallery organ silent
 Transposer
 Gallery reversibles to Chancel
 Tutti I
 Tutti II
 Tutti III
 Tutti IV
 Crescendo (bar graph)
 Carillon Inside
 Carillon Outside
 Memory level (digital readout)
 Crescendo level (digital readout)
 Signal

Lights for music rack and pedalboard

Auxiliary duplex outlets

Power switch

Monitor Speakers switch

Console light switch (controls music rack and pedal lights)

Volume controls: (1) Harp percussions/Chimes, (2) Carillon

Sustain Switch (Harp percussions)

Swell expression pedal (also operates Gallery Swell expression)

Choir expression pedal

Solo expression pedal

Crescendo pedal with adjustable Celestes/Tremulants cutout

Crescendo selector piston

(1 fixed setting, 3 adjustable settings)

Transposer

Sequencer

Adjustable bench

Westwood United Methodist Church

10497 Wilshire Boulevard

Los Angeles, CA 90024-4606

310/474-4511