

SPECIFICATIONS

MAIN CHAMBER

(Left Side)

English Post Horn
Tuba Horn
Oboe Horn
Clarinet
Tibia Clausa
Horn Diapason
Quintadena
Quintadena Celeste
Gamba
Gamba Celeste
Concert Flute
Flute Celeste
Lieblich Flute
Violin
Violin Celeste
Telephone Bell
Splash Cymbal
Wind Chimes
Vox Humana
Double String Bass
Contra Bourdon 32'

SOLO CHAMBER

(Right Side)

Solo English Post Horn
Tuba Mirabilis
Solo Tibia Clausa
Brass Trumpet
Open Diapason
Viol d'Orchestre
Viol Celeste
Gemshorn
Gemshorn Celeste
Krumet
Orchestral Oboe
Brass Saxophone
Kinura
Musette
Solo Vox Humana

CLASSIC DIVISION

(In Front of Piano)

4' Principal

Mixture III

RIGHT WALL

16' & 8' Pedal Tibia Clausa

Cathedral Chimes

BACK WALL

MAIN TOY COUNTER

(In Front of Main Chamber)

Snare Drum
Tambourine
Shuffle
Diesel Horn
Siren
Klaxon
Choke Cymbal
Finger Cymbals
Brush & Tap Cymbal
Police Whistle
Bird Whistle I

SOLO TOY COUNTER

(In Front of Solo Chamber)

Cow Bell
Horse Hoofs
Fire Gong
Sleigh Bells
Train Whistle
Castanets
Wood Block
Bird Whistle II
Triangle
Ah-Ooh-Ga Horn
Slide Whistle
Roll Cymbal

DRUM COUNTER

(Right Wall)

Gong
Bongo Drum
Conga Drum
UNENCLOSED
PERCUSSIONS
(Left Dining Room)
Marimba Harp
Chrysoglott
Piano (Alcove Above Console)
(Right Side of Dining Room)
Master Xylophone
Glockenspiel
Sleigh Bells