1/ Quintaton 16'
2/ Open Diapason 8'
3/ Hohl Flöte 8'
4/ Spitz Flöte 8'
5/ Flute Celeste (TC)8'
6/ Principal 4'
7/ Harmonic Flute 4'
8/ Gemshorn 4'
10/ Fifteenth 2'
Sub Octave
Unison off
Tremulant

11/ Contra Gamba 16', 22/ Sub Bass (Bourdon) 16'
12/ Horn Diapason 8'
13/ Doppelflöte 8' 24/ Gamba (from 1) 16'
13/ Doppelflöte 8' 24/ Gamba (from 11) 16'
14/ Salicional 8' 25/ Gross Quint 10'3'
15/ Gamba 8'(from 11) 26/ Octave
8'
16/ Gamba Celeste(4)27/ Flute Bass (20 form 22) 8'
17/ Octave Gamba 4' 28/ Gamba (from 11) 8'
18/ Rohr Flöte 4' 29/ Quint (20 from 25) 5'
19/ Cornet 12/15/17/30/ Super Octave (20 from 26) 4'
20/ Trumpet 8'
Sub Octave Gamba (from 11) 4'
21/ Vox Humana 8'
32/ Trombone
Sub Octave
Unison off
Tremulant

Couplers: Gt to Pedal; Gt super to Pedal; Sw to Pedal; Swell super to Pedal; Sw to Gt; Sw super to Gt; Sw sub to Gt

4 adjustable combination pistons each to Gt, Sw and Pedal plus 4 (foot) pistons acting on all stops and couplers. Adjuster and general release.

Reversible pistons: Gt to Pedal (duplicated by foot); Sw to Pedal: Sw to Gt.

Balanced Pedals: Expression pedals to Gt and Sw; Cresc. pedal acting on all stops and couplers.

Detached console of oak. Electro-pneumatic action. Manuals: 61 keys